



\*Designates those parts included in repair kit #205500.

REPLACEMENT  
PARTS

MODEL NO.  
71500

CAPACITY  
5 TON

DESCRIPTION  
HYDRAULIC FLOOR SERVICE JACK

**norco**

INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Handle assembly <i>includes:</i>	203010	1
2	Handle cap	203001	1
3	Spring	203002	1
4	Valve control rod	203002	1
5	Valve control lever	203006	1
6	Handle	203004	1
7	Handle fork	205011	1
8	Lockwasher	203017	1
9	Set screw, handle	203018	1
10	Collar	205019	1
11	Bracket, handle fork	205020	1
12	Cam step	205027	1
13	Roll pin	203038	1
14	Foot pedal, with pin	205040	1
15	Connecting bar	205045	1
*16	Cotter pin	27006	1
17	Pin, connecting	205051	1
18	Cotter pin	205052	1
19	Spring	205053	1
20	Snap ring	215051	1
21	Handle shaft	205054	1
22	Lock washer	22002	4
23	Bolt	205056	4
24	Caster assembly <i>includes:</i>	205060	2
25	Grease nipple	203051	2
26	Bolt	31003	4
27	Lock washer	22002	4
28	Rivet	203508	4
29	Screw	205071	2
30	Bolt, spring retaining	203511	2
31	Nut	205072	2
32	Washer	205073	2
33			
34	Nut	203514	2
35	Lock washer	205076	2
36	Grease nipple	203051	2
37	Roller bearing (11 per wheel)	205077	22
38	Arm stopper	205078	1
39	Front wheel	205079	2
40	Washer	205081	4

INDEX NO.	DESCRIPTION	PART NO.	QTY.
41	Snap ring	205082	2
42	Frame assembly	205100	1
43	Spring	205101	2
44	Shaft, spring retaining	205102	1
45	Connecting joint, piston	205151	1
46	Piston pin	205152	1
47	Bolt	205153	1
*48	Packing seal, piston	205154	1
49	Tank nut	205156	1
*50	Gasket, fiber	205157	2
51	Ring assembly	205160	1
52	Piston rod sub-assy <i>includes:</i>	205170	1
53	Piston rod	205171	1
54	Housing, by-pass valve	203329	1
55	Rod, by-pass	203328	1
*56	Steel ball, .188 dia.	9007	1
*57	Spring, by-pass	203326	1
*58	Copper packing	203324	1
59	Packing retainer, piston	205172	1
*60	Packing, U-type	205173	1
61	Oil box & cylindere assembly	205200	1
*62	Check ball, .313 dia.	9005	1
63	Spacer, check ball	205211	1
*64	Check ball, .500 dia.	9006	1
65	Spacer, check ball	205212	1
*66	Copper packing	203306	1
67	Cap plug	203307	1
68	Oil strainer	205213	1
*69	Copper packing	203233	1
70	Pump cylinder	203232	1
*71	O-ring	203231	1
*72	Back-up ring	203229	1
*73	Rubber packing, plunger	203228	1
*74	Copper packing	203227	1
75	Housing, release valve	203226	1
76	Release valve	203224	1
77	Cotter pin	203223	1
78			
79	Lock nut	203222	2
80	Spring	203221	1

INDEX NO.	DESCRIPTION	PART NO.	QTY.
81	Connecting pin, release valve	203219	1
*82	O-ring	203218	1
*83	Rubber packing	205214	1
84	Pipe nipple	203216	1
85	Cork packing	203214	1
86	Oil tank	205216	1
87	Rubber packing	203203	1
88	Cap nut	203202	1
89	Pump plunger	203201	1
90	Connecting bar, release valve	205221	1
91	Fork	203207	1
92	Cotter pin	203206	1
93	Lock nut	203222	1
94	Bolt	205222	1
*95	Washer	205223	1
*96	Diaphragm	203212	1
97	Cover, oil tank	203211	1
98	Bolt	203209	4
99	Cover	205226	1
100	Arm pin	205227	1
101	Arm and link assembly	205250	1
102	Grease nipple	215122	1
103	Saddle	203371	1
104	Pin, link rod	205259	2

\*Designates those parts included in repair kit #205500.